


wood venetian blinds

how to measure

Measuring your windows is not a difficult task. Follow the instructions to ensure a good fit for your blinds. Please measure in centimeters all though inches are acceptable. Before you start to measure you must first decide whether you would like your blind to hang inside or outside the window recess.


Inside Recess Fitting



Inside Recess Fitting

- 1) Measure the width in 3 different positions inside the window recess from wall to wall. Measure on the left, the middle and the right. The most important measurement to write down is the smallest one.
- 2) Measure the Drop (height) in 3 different positions inside the recess from the top of the recess to the window sill. Once again the most important measurement to write down is the smallest one.
- 3) Enter these measurements into the relevant input boxes on the Online Store page of this website.

Outside Recess Fitting



Outside Recess Fitting

- 1) Measure the width of your window then add at least 12cm to allow for overlap.
- 2) Measure the drop (height) of your window and add at least 12cm to allow for overlap.
- 3) Remember to enter your sizes as Exact size when ordering for outside recess this will mean the blind will be made to your precise measurements.

Note:

Always measure every window as no two windows are the same size. Blinds are custom made to fit each window. Please re check your measurements before ordering your blinds, any help required measuring for bay windows, conservatories or just general information please call our customer services on 0800 174313 Monday to Friday 09.30am till 5.00pm.